

WABCO V13.06 Function List

Note:

✓ Functions marked with ✓ is fully supported.

| System | ECU Info | Read Fault Code | Clear Fault Code | Live Data | Active Test | Special Func |
|---|----------|-----------------|------------------|-----------|---|--|
| WABCO System Diagnostic Software Search | ✓ | ✓ | ✓ | | | |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\Auto detect | ✓ | ✓ | ✓ | | | |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS C | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0014, A0137, A0138, A0139, A0140, A0141, A0142, A0495, A0030, A0031, A0032, A0033, A0002, A0034, A0035, A0036, A0037, A0038, A0039, | S0003, S0015 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS D Hydraulic | ✓ | ✓ | ✓ | ✓ | A0001, A0002, A0003, A0004, A0005, A0006, A0007, A0008, A0009, A0010, A0011, A0496, A0016, A0017, A0018, A0019, A0020, A0021, A0022, A0023, A0024, | S0001, S0001 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS D+\Start KWP 2000 | ✓ | ✓ | ✓ | ✓ | A0503, A0504, A0505, A0506, A0507, A0508, A0509, A0510, A0031, A0032, A0033, A0034, A0035 | S0001, S0018, S0016 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS D+\Start JED677 (ISO) | ✓ | ✓ | ✓ | ✓ | A0004, A0005, A0006, A0007, A0008, A0009, A0010, A0073, A0074, A0075, A0076, A0077, A0078, A0079, A0080, A0081, A0082, A0083, A0084 | S0001, S0010, S0011 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS E+\ABS E+ UDS | ✓ | ✓ | ✓ | ✓ | | S0001 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS E+\ABS E+ KWP2000 | ✓ | ✓ | ✓ | ✓ | A0003, A0004, A0005, A0011, A0012, A0013, A0014, A0009, A0015 | S0001 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS E+\ABS E+ J1708 | ✓ | ✓ | ✓ | ✓ | A0094, A0095, A0096, A0097, A0098, A0099, A0511, A0512, A0513, A0514 | S0002, S0015 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS HPB | ✓ | ✓ | ✓ | ✓ | A0482, A0483, A0484, A0485, A0486, A0487, A0488, A0489, A0490, A0491, A0492, A0493, A0494, A0036, A0037, A0038, A0035, A0039, A0040 | S0015, S0016, S0017, S0017, S0017, S0017 |
| Diagnostics Truck and Bus\ABS (Anti Lock Brake System)\ABS SAE | ✓ | ✓ | ✓ | ✓ | A0029, A0030, A0159, A0016, A0017, A0018, A0019, A0020, A0021, A0022, A0023, A0024, A0025, A0014, A0296, A0297, A0298, A0299, A0300, A0301, A0010, | S0003 |
| Diagnostics Truck and Bus\ATC (Automatic Transmission System)\ATC Coach | ✓ | ✓ | ✓ | ✓ | A0014, A0010, A0039, A0040, A0041, A0042, A0043, A0044, A0045, A0046, A0047, A0048, A0049, A0050, A0051, A0052, A0053, A0054, A0055, A0056, A0057, | S0019, S0021, S0006 |
| Diagnostics Truck and Bus\ATC (Automatic Transmission System)\ATC KWP Citaro Travego | ✓ | ✓ | ✓ | ✓ | A0014, A0010, A0016, A0001, A0002, A0003, A0004, A0005, A0324, A0325, A0326, A0327, A0328, A0329, A0330, A0331, A0332, A0333, A0334, A0335, A0336, | S0002, S0004, S0005, S0020, S0003, S0019, S0001 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\Auto detect | ✓ | ✓ | ✓ | | | |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS 3 | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0013, A0014, A0498, A0499, A0500, A0501, A0502 | S0003, S0014, S0015 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS Bus Standard | ✓ | ✓ | ✓ | ✓ | A0073, A0031 | S0016 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS CBU MAN | ✓ | ✓ | ✓ | ✓ | A0014, A0015, A0074, A0073, A0075, A0010, A0160, A0161, A0162, A0163, A0164, A0029, A0030, A0031, A0032, A0033, A0034, A0035, A0036, A0037, A0038, | S0004, S0017, S0018, S0005, S0003 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS EPB Bus | ✓ | ✓ | ✓ | ✓ | A0026 | S0012, S0013, S0014, S0015, S0016, S0017, S0018, S0019 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS EPB MB Truck | ✓ | ✓ | ✓ | ✓ | A0001, A0002, A0003, A0004, A0005, A0006, A0007, A0008, A0009 | S0001 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS Euro\Start K-Line | ✓ | ✓ | ✓ | ✓ | | S0001 |
| Diagnostics Truck and Bus\EBS (Electronic Brake System)\EBS Euro\Start CAN | ✓ | ✓ | ✓ | ✓ | A0100, A0101, A0102, A0103, A0104, A0105, A0106, A0107, A0108, A0109, A0110, A0111, A0112, A0113, A0114, A0115, A0116, A0117, A0118, A0119, A0120, | S0001 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS 4x2 S20000 | ✓ | ✓ | ✓ | ✓ | A0003, A0004, A0005, A0080, A0081, A0082, A0083, A0084, A0085, A0511, A0512, A0513, A0514, A0016, A0070, A0071 | S0001 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS Bus A | ✓ | ✓ | ✓ | ✓ | A0622, A0623, A0624, A0625, A0626, A0627, A0628, A0629, A0016, A0017, A0018, A0019, A0016, A0017, A0018, A0019, A0016, A0017, A0018, A0019, A0016, A0017, | S0002, S0001, S0002, S0003 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS Bus Citaro\Front section/solo | ✓ | ✓ | ✓ | ✓ | | S0008, S0009 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS Bus Citaro\Rear section | ✓ | ✓ | ✓ | ✓ | A0001, A0002, A0003, A0004, A0005, A0006, A0007, A0008, A0009, A0010, A0011, A0012, A0013, A0014, A0015, A0016, A0017, A0018, A0019, A0020, A0021, | S0006, S0007, S0008, S0009 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS CAN2\K-line truck and bus front section | ✓ | ✓ | ✓ | ✓ | A0027, A0028, A0098, A0099, A0100, A0101, A0102, A0103, A0104, A0105, A0106, A0107, A0108, A0109, A0110, A0111, A0112, A0096, A0097, A0113, A0114, | S0019, S0020, S0012, S0013, S0014, S0015, S0016, S0017, S0018, S0001, S0002, S0002, S0001, S0003, S0004, S0001 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS CAN2\K-line bus rear section | ✓ | ✓ | ✓ | ✓ | A0027, A0028, A0098, A0099, A0100, A0101, A0102, A0103, A0104, A0105, A0106, A0107, A0108, A0109, A0110, A0111, A0112, A0096, A0097, A0113, A0114, | S0019, S0020, S0012, S0013, S0014, S0015, S0016, S0017, S0018, S0001, S0002, S0002, S0001, S0003, S0004, S0001 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS CAN2\CAN truck and bus front section | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0014, A0135, A0136, A0137, A0138, A0104, A0139, A0140, A0141, A0127, A0142, A0143, A0015, A0144, A0098, A0145, A0146, | S0003, S0004, S0030, S0031, S0032, S0033, S0005, S0006, S0007, S0008, S0009, S0003, S0010, S0011, S0003, S0010, S0008, S0009, S0008, S0009, S0008, |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS CAN2\CAN bus rear section | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0015, A0014, A0271, A0272, A0273, A0274, A0275, A0271, A0272, A0273, A0274, A0275, A0271, A0272, A0273, A0274, A0275, | S0003, S0004, S0005 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS ENR MB Truck | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0014, A0130, A0131, A0132, A0133, A0134, A0135, A0136 | S0003, S0004 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS Truck JED | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0014, A0160, A0161, A0162, A0163, A0164, A0041, A0061, A0062, A0063, A0025, A0064, A0065, A0041, A0061, A0062, A0063, | S0003, S0004 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\ECAS Truck KWP K | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0015, A0014, A0526, A0110, A0527, A0528, A0529, A0530, A0531, A0532, A0041, A0042, A0043, A0044, A0017, A0041, A0042, | S0003, S0004, S0005 |
| Diagnostics Truck and Bus\ECAS (Electronically Controlled Air Suspension System)\Air Suspension(Wabco ECAS) | ✓ | ✓ | ✓ | ✓ | A0010, A0011, A0012, A0013, A0014, A0029, A0030, A0031, A0032, A0033, A0034, A0035, A0036, A0037, A0038, A0296, A0297, A0298, A0299, A0300, A0301, | S0003, S0004 |

| | | | | | | |
|---|---|---|---|---|--|--|
| Diagnostics Truck and Bus\EPS (Electric Power Steering System)\EPS | ✓ | ✓ | ✓ | ✓ | A0016, A0014, A0016, A0017, A0018, A0019, A0020, A0021, A0022, A0023, A0024, A0025, A0296, A0297, A0298, A0299, A0300, A0301 | S0003 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Towing vehicle / Bus\TRUCK 5V CAN | ✓ | ✓ | ✓ | ✓ | A0016, A0014, A0010, A0013 | S0003 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Towing vehicle / Bus\MAN/FFR K-Line | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014 | S0006 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer\IVTM 5V-CAN | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0039, A0039, A0039, A0039, A0039, A0040, A0040, A0040, A0040, A0040, A0041, A0041, | S0021 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer\TCE/TEBS K-Line | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0515, A0516 | S0006, S0019 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer\ISO 7638 24V-CAN | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0039, A0039, A0039, A0039, A0039, A0040, A0040, A0040, A0040, A0040, A0041, A0041, | S0021 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Dolly\IVTM 5V-CAN | ✓ | ✓ | ✓ | ✓ | A0014, A0001, A0002, A0003, A0004, A0005, A0324, A0325, A0326, A0327, A0328, A0329, A0330, A0331, A0332, A0333, A0334, A0335, A0336, A0337, A0338, | S0004, S0005, S0001, S0019, S0002, S0003 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Dolly\TCE/TEBS K-Line | ✓ | ✓ | ✓ | ✓ | A0302, A0303, A0304, A0305, A0306, A0307, A0308, A0309, A0310, A0311, A0312, A0313, A0314, A0315, A0316, A0317, A0318, A0319, A0320, A0321, A0322, | S0014 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Dolly\ISO 7638 24V-CAN | ✓ | ✓ | ✓ | ✓ | A0014, A0001, A0002, A0003, A0004, A0005, A0324, A0325, A0326, A0327, A0328, A0329, A0330, A0331, A0332, A0333, A0334, A0335, A0336, A0337, A0338, | S0004, S0005, S0001, S0019, S0002, S0003 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\WABCO state on delivery(address CF hex / 207 dec) | ✓ | ✓ | ✓ | ✓ | A0397, A0400, A0401, A0402, A0403, A0404, A0405, A0406, A0407, A0422, A0423, A0410, A0411, A0412, A0424, A0425, A0426, A0427, A0428, A0429, A0408, | S0019, S0042, S0043, S0004, S0005, S0006, S0007, S0011 |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\1st trailer in trailer train(address C8 hex / 200 dec) | ✓ | ✓ | ✓ | | A0394, A0395, A0396, A0397, A0400, A0401, A0402, A0403, A0404, A0405, A0406, A0407, A0422, A0423, A0410, A0411, A0412, A0424, A0425, A0426, A0427, | |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\2nd trailer in trailer train(address C0 hex / 192 dec) | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\3rd trailer in trailer train(address B8 hex / 184 dec) | ✓ | ✓ | ✓ | ✓ | A0012, A0013, A0014, A0015 | |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\4nd trailer in trailer train(address B0 hex / 176 dec) | ✓ | ✓ | ✓ | ✓ | A0076, A0073, A0077 | |
| Diagnostics Truck and Bus\TPMS (Tire Pressure Monitoring System)\OptiTire (IVTM)\Trailer train\5nd trailer in trailer train(address A8 hex / 168 dec) | ✓ | ✓ | ✓ | | | |
| Diagnostics Truck and Bus\ADAS (Advanced Driving Assistance System)\OnGuard Anti-Collision | ✓ | ✓ | ✓ | ✓ | A0480, A0481 | |
| Diagnostics Truck and Bus\ADAS (Advanced Driving Assistance System)\OnLane LDW (OnLaneNextGen) | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Truck and Bus\others\HBS AddOn-E | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Truck and Bus\others\MTS | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Truck and Bus\others\ZBR2 | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Trailer\OptiTire (IVTM)\Towing vehicle / Bus\TRUCK 5V CAN | ✓ | ✓ | ✓ | ✓ | A0016, A0014, A0010, A0013 | S0003 |
| Diagnostics Trailer\OptiTire (IVTM)\Towing vehicle / Bus\MAN/FFR K-Line | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014 | S0006 |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer\IVTM 5V-CAN | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0039, A0039, A0039, A0039, A0039, A0040, A0040, A0040, A0040, A0040, A0041, A0041, | S0021 |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer\TCE/TEBS K-Line | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0515, A0516 | S0006, S0019 |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer\ISO 7638 24V-CAN | ✓ | ✓ | ✓ | ✓ | A0010, A0016, A0017, A0013, A0014, A0039, A0039, A0039, A0039, A0039, A0040, A0040, A0040, A0040, A0040, A0041, A0041, | S0021 |
| Diagnostics Trailer\OptiTire (IVTM)\Dolly\IVTM 5V-CAN | ✓ | ✓ | ✓ | ✓ | A0014, A0001, A0002, A0003, A0004, A0005, A0324, A0325, A0326, A0327, A0328, A0329, A0330, A0331, A0332, A0333, A0334, A0335, A0336, A0337, A0338, | S0004, S0005, S0001, S0019, S0002, S0003 |
| Diagnostics Trailer\OptiTire (IVTM)\Dolly\TCE/TEBS K-Line | ✓ | ✓ | ✓ | ✓ | A0302, A0303, A0304, A0305, A0306, A0307, A0308, A0309, A0310, A0311, A0312, A0313, A0314, A0315, A0316, A0317, A0318, A0319, A0320, A0321, A0322, | S0014 |
| Diagnostics Trailer\OptiTire (IVTM)\Dolly\ISO 7638 24V-CAN | ✓ | ✓ | ✓ | ✓ | A0014, A0001, A0002, A0003, A0004, A0005, A0324, A0325, A0326, A0327, A0328, A0329, A0330, A0331, A0332, A0333, A0334, A0335, A0336, A0337, A0338, | S0004, S0005, S0001, S0019, S0002, S0003 |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\WABCO state on delivery(address CF hex / 207 dec) | ✓ | ✓ | ✓ | ✓ | A0397, A0400, A0401, A0402, A0403, A0404, A0405, A0406, A0407, A0422, A0423, A0410, A0411, A0412, A0424, A0425, A0426, A0427, A0428, A0429, A0408, | S0019, S0042, S0043, S0004, S0005, S0006, S0007, S0011 |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\1st trailer in trailer train(address C8 hex / 200 dec) | ✓ | ✓ | ✓ | | A0394, A0395, A0396, A0397, A0400, A0401, A0402, A0403, A0404, A0405, A0406, A0407, A0422, A0423, A0410, A0411, A0412, A0424, A0425, A0426, A0427, | |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\2nd trailer in trailer train(address C0 hex / 192 dec) | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\3rd trailer in trailer train(address B8 hex / 184 dec) | ✓ | ✓ | ✓ | ✓ | A0012, A0013, A0014, A0015 | |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\4nd trailer in trailer train(address B0 hex / 176 dec) | ✓ | ✓ | ✓ | ✓ | A0076, A0073, A0077 | |
| Diagnostics Trailer\OptiTire (IVTM)\Trailer train\5nd trailer in trailer train(address A8 hex / 168 dec) | ✓ | ✓ | ✓ | | | |
| Diagnostics Trailer\TEBS-D\Start CAN (trailer socket) | ✓ | ✓ | ✓ | ✓ | | S0070 |
| Diagnostics Trailer\TEBS-D\Start K-line (diagnosis socket) | ✓ | ✓ | ✓ | ✓ | A0702, A0703, A0704, A0705, A0706, A0707, A0708, A0709, A0710 | S0074, S0075, S0099, S0076 |

| | | | | | | |
|---|---|---|---|---|--|---|
| Diagnostics Trailer\TEBS-E\Start 24V CAN | ✓ | ✓ | ✓ | ✓ | | S0071, S0072, S0073 |
| Diagnostics Trailer\TEBS-E\Start 5V CAN | ✓ | ✓ | ✓ | ✓ | A0156, A0157, A0158, A0006 | |
| Diagnostics Trailer\Trailer CAN Router-Repeater | ✓ | ✓ | ✓ | ✓ | | |
| Diagnostics Trailer\TCE (Trailer Central Electronic)\Start (K-line) | ✓ | ✓ | ✓ | ✓ | A0008, A0009, A0662, A0663, A0664, A0665, A0666, A0667, A0668, A0669, A0670, A0671, A0647, A0672, A0673, A0674 | S0074, S0075, S0076 |
| Diagnostics Trailer\TCE (Trailer Central Electronic)\Start (CAN 24V) | ✓ | ✓ | ✓ | ✓ | A0675, A0676, A0677, A0678, A0679, A0680, A0681, A0682, A0683 | S0077, S0078, S0079, S0080, S0081 |
| Diagnostics Trailer\VCS II\Start K-line (diagnostics socket) | ✓ | ✓ | ✓ | ✓ | A0086, A0087, A0088, A0089, A0090, A0091, A0092, A0093 | S0022, S0023 |
| Diagnostics Trailer\VCS II\Start CAN (trailer socket) | ✓ | ✓ | ✓ | ✓ | A0145, A0146, A0147, A0684 | S0024, S0025, S0026, S0027, S0028, S0029, S0082 |
| Diagnostic Software - WABCO North America\Pneumatic ABS | ✓ | ✓ | ✓ | ✓ | A0148, A0149, A0150, A0151, A0152, A0153, A0154, A0155, A0685, A0686, A0687, A0688, A0689 | S0083, S0084 |
| Diagnostic Software - WABCO North America\ST Hydr J1939 | ✓ | ✓ | ✓ | ✓ | A0148, A0149, A0150, A0151, A0152, A0153, A0154, A0155, A0058, A0059, A0060 | S0008, S0009, S0010 |
| Diagnostic Software - WABCO North America\Tractor ABS Diagnosis (J1708) | ✓ | ✓ | ✓ | ✓ | A0149, A0150, A0151, A0152, A0153, A0154, A0155, A0078, A0001, A0002, A0003, A0004, A0005, A0006, A0007, A0008, A0009, A0010, A0011, A0079, A0143, | S0042, S0043, S0019 |
| Diagnostic Software - WABCO North America\Hydraulic ABS Diagnosis (J1708) | ✓ | ✓ | ✓ | ✓ | A0149, A0150, A0151, A0152, A0153, A0154, A0155, A0078, A0001, A0002, A0003, A0004, A0005, A0006, A0007, A0008, A0009, A0010, A0011, A0079, A0143, | S0042, S0043, S0019 |
| Diagnostic Software - WABCO North America\Trailer ABS Diagnosis (J1708) | ✓ | ✓ | ✓ | ✓ | A0073, A0077, A0020, A0021, A0022, A0023, A0024 | S0004, S0005, S0006, S0007 |
| Diagnostic Software - WABCO North America\Trailer iABS Diagnosis (J1708) | ✓ | ✓ | ✓ | ✓ | A0021, A0075 | S0005, S0011 |
| Diagnostic Software - WABCO North America\Trailer RSS Diagnosis (J1708) | ✓ | ✓ | ✓ | ✓ | A0515, A0516, A0072, A0073, A0074 | S0019 |
| Diagnostic Software - WABCO North America\Bus ECAS (J1708) | ✓ | ✓ | ✓ | ✓ | | |

| Special Function Table | |
|------------------------|--|
| S0001 | Calibrate the distance sensors |
| S0002 | Calibration data of the distance sensors |
| S0003 | Calibration data of the pressure sensors |
| S0004 | Change Service Odometer |
| S0005 | Tire Calibration |
| S0006 | Netobook |
| S0007 | Lift Axle |
| S0008 | Utility/reset ECU |
| S0009 | Utility/engineering data |
| S0010 | End of Line(EOL)/system checked bit |
| S0011 | Reconfigure iABS ECU |

| Active Test Table | |
|-------------------|---------------------------------|
| A0001 | Valves |
| A0002 | Trailer Brake Valve |
| A0003 | E4.3 Trailer Brake Valve |
| A0004 | E4.3 TBV With ABS Valve |
| A0005 | ABS Lamp |
| A0006 | ATC Lamp |
| A0007 | Trailer Lamp |
| A0008 | Retarder Relady |
| A0009 | Engine Data Link |
| A0010 | Disable ATC |
| A0011 | Enable ATC |
| A0012 | Miscellaneous Outputs |
| A0013 | Actuate Outputs |
| A0014 | Brake Lamp |
| A0015 | Actuate Parking Brake |
| A0016 | Lifting/Lowering |
| A0017 | Lamp test |
| A0018 | Throttle |
| A0019 | Outputs |
| A0020 | Valve Activation |
| A0021 | Test Warning Lamp |
| A0022 | Sensor Test |
| A0023 | Reconfigure |
| A0024 | Sensors Facing |
| A0025 | warning lamp |
| A0026 | ASR Lamp |
| A0027 | Retarder/Engine brake actuation |
| A0028 | Engine interface actuation |
| A0029 | DIF valve actuation |
| A0030 | Actuating the modulators |
| A0031 | Lamps |
| A0032 | Endurance brake deactivation |
| A0033 | Modulator Actuation |
| A0034 | Differential valve |

| | |
|-------|--|
| A0035 | Engine interface |
| A0036 | Lamps And Buzzers |
| A0037 | Relays |
| A0038 | Flushing procedure |
| A0039 | Sensor/Pole Wheel Test |
| A0040 | Sensor/Modulator Assignment Check |
| A0041 | Front axle Middle |
| A0042 | Rear axle Left |
| A0043 | Rear axle Right |
| A0044 | Rear axle Middle |
| A0045 | Lifting axle/tag axle Left |
| A0046 | Lifting axle/tag axle Right |
| A0047 | Lifting axle/tag axle Lifting/lowering |
| A0048 | Lifting axle/tag axle Lifting bellows |
| A0049 | Warning lamp |
| A0050 | Control element |
| A0051 | Substation 0 |
| A0052 | Substation 1 |
| A0053 | Substation 2 |
| A0054 | Maximum Heat |
| A0055 | Maximum cooling |
| A0056 | Fill cooling agent |
| A0057 | Fill cooling water |
| A0058 | Enable/Disable ATC |
| A0059 | Miscellaneous components |
| A0060 | Activate valves |
| A0061 | Rear axle left |
| A0062 | Rear axle right |
| A0063 | Rear axle middle |
| A0064 | LSV valve |
| A0065 | Safety lamp |
| A0066 | Lifting bellows |
| A0067 | Lifting Axle Position/Tag Axle Status |
| A0068 | Traction help |
| A0069 | Lifting axle position/tag axle status or traction help |
| A0070 | Venting valve |
| A0071 | Compressor |
| A0072 | Redundancy Test |
| A0073 | Lamp Test |
| A0074 | Suspension Calibration |
| A0075 | Select Valve to Activate |
| A0076 | Warning Lamp |
| A0077 | Height Sensor of Vehicle's Lamp |
| A0078 | Buzzer |
| A0079 | Lateral Throttle Valve |
| A0080 | Vehicle Height Control Valve Fine Adjustment Up |
| A0081 | Vehicle Height Control Valve Fine Adjustment Down |
| A0082 | Front Valve Fine Adjustment Up |
| A0083 | Front Valve Fine Adjustment Down |
| A0084 | Rear Valve Fine Adjustment Up |
| A0085 | Rear Valve Fine Adjustment Down |
| A0086 | Right Valve Fine Adjustment Up |
| A0087 | Right Valve Fine Adjustment Down |
| A0088 | Left Valve Fine Adjustment Up |
| A0089 | Left Valve Fine Adjustment Down |
| A0090 | Front Right Valve Fine Adjustment Up |
| A0091 | Front Right Valve Fine Adjustment Down |
| A0092 | Front Left Valve Fine Adjustment Up |
| A0093 | Front Left Valve Fine Adjustment Down |
| A0094 | Rear Right Valve Fine Adjustment Up |
| A0095 | Rear Right Valve Fine Adjustment Down |
| A0096 | Rear Left Valve Fine Adjustment Up |
| A0097 | Rear Left Valve Fine Adjustment Down |