

CASE V13.2 Function List

Note:

✓ Functions marked with ✓ is fully supported.

System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBxxxxx)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBxxxxx)\ADIC Analog/Digital Inst Cluster	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBxxxxx)\GA Power Take-off Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBxxxxx)\Steer Steering Controller	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\ATC Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\ECM Engine Control Module				✓	A0011, A0012, A0013, A0010, A0014	
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\EDC Electronic Draft Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\EPL Electronic Park Lock	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\FEHR Front Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\ICP Integrated Control Panel	✓			✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\RPTO Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\TCU Tractor Control Unit	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 - ZDRH00915, ZERH02500 - ZERH08000)\Trans Transmission Control		✓	✓	✓	A0015	
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ECM Engine Control Module				✓	A0011, A0012, A0013, A0010, A0014	
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Trans Transmission Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\RPTO Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\4WD 4WD Diff Lock Control		✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\SSS Secondary Steering System	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ATC Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Hitch Electronic Hitch Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\FHC Front Hitch Control		✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B - Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 - Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ICP Integrated Control Panel				✓		

CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\Eng Engine Controller				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\Trans Transmission/Suspension				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\Arm RH Armrest Controller				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\TMF Tractor Multi-Function				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\Inst Tractor Monitor				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (N.A. Models 215, 245, 275, 305, 335) (EU Models 225, 250, 280, 310, 335) (P.I.N. Z7RZ05000 - ZBRZ01882)\ATC Auto Temperature Controller	✓			✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\ATC Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\ECM Engine Control Module				✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\EDC Electronic Draft Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\EPL Electronic Park Lock	✓	✓	✓	✓	Please refer to NEWHOLLAND Function List	
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\FEHR Front Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\ICP Integrated Control Panel	✓			✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\RPTO Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\TCU Tractor Control Unit	✓	✓	✓	✓	Please refer to NEWHOLLAND Function List	
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P.I.N. ZxES00001 - ZxES99999)\Trans Transmission Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\Tier 3 NEF (EDC16C39)	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\4WD 4WD Diff Lock Control			✓	✓	✓	
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\ATC Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\EDC Electronic Draft Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\EPL Electronic Park Lock	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\FEHR Front Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\FHC Front Hitch Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\FPTO Front PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\ICP Integrated Control Panel	✓			✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\RM Suspension Front Axle Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\RPTO Rear PTO Control		✓	✓	✓		

CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 165, 180, 195, 210) (with 18/19x6 Full Power Shift) (with MultiControl Armrest) (Tier 3) (P.I.N. ZxBH40001 - ZxBH99999)\RT Electronic Transmission	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Eng Engine Controller				✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Trans Transmission Control				✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Arm RH Armrest Controller	✓			✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Steer Steering Controller				✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Inst Tractor Monitor	✓			✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\ATC Auto Temperature Controller	✓			✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\AUX Remote Hydraulic Controller				✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Hitch Hitch Controller				✓		
CASE\CASE IH AG\TRACTORS\STX Steiger Tractor (P.I.N. Z5F100001 - Z7F106315)\Perf Performance Monitor				✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 4077 / 4088 Midrange Combines\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 4077 / 4088 Midrange Combines\Eng Engine Controller				✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 4077 / 4088 Midrange Combines\AP2 A Post 2 Instrument Cluster	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\EGM Engine Governor Module				✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\ATC Auto Temperature Controller	✓	✓	✓			
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\CCM1 Combine Control Module 1	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\CCM2 Combine Control Module 2	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\CCM3 Combine Control Module 3	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7120 8120 9120 Combine (P.I.N. Y8G205001 and Above) (P.I.N. YAJ000001 and Above)\RHM Right Hand Module	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 5088, 6088, 7088, 2566, 2688, 2799 Combine (With Cummins Engines)\ATC Auto Temperature Controller	✓	✓	✓			
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 5088, 6088, 7088, 2566, 2688, 2799 Combine (With Cummins Engines)\AP2 A Post 2 Instrument Cluster	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 5088, 6088, 7088, 2566, 2688, 2799 Combine (With Cummins Engines)\CXC Combine Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\ECM Engine Control Module				✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\CCM1 Combine Control Module 1	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\CCM2 Combine Control Module 2	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\CCM3 Combine Control Module 3	✓			✓		
CASE\CASE IH AG\HARVESTING EQUIPMENT\Axial-Flow 7230 8230 9230 Flagship Combine (P.I.N. YCG214801 - YDG218531)\RHM Right Hand Module	✓			✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0003, S0004, S0005, S0006, S0007, S0008
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\ECM Engine Control Module				✓	A0007, A0009, A0010	S0002, S0009, S0004, S0006, S0008, S0010, S0011
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		

CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\Eng Engine Controller				✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\Eng Engine Controller				✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SR+, 590SR, 695SR, 580ST, 590ST, 695ST)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SM, 580SM+, 590SM, 590SM+)\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SM, 580SM+, 590SM, 590SM+)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SM, 580SM+, 590SM, 590SM+)\Eng Engine Controller				✓		
CASE\CASE CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SM, 580SM+, 590SM, 590SM+)\Trans Transmission Controller	✓			✓		
CASE\CASE CE EUR (Light)\COMPACT WHEEL LOADERS\Wheel Loaders (Models 021F, 121F, 221F STD, 221F HS, 321F STD, 321F HS)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM Catalyst)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM Catalyst)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0002, S0014, S0003, S0004, S0005, S0006, S0007, S0008, S0011
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM Catalyst)\IC Instrument Cluster	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0009, S0004, S0006, S0008, S0010, S0011
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\IC Instrument Cluster	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\SR175 / SV185 Series Skid Steer Loaders (with Tier 4 ISM DI Engine)\ECM Engine Control Module				✓		
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\SR175 / SV185 Series Skid Steer Loaders (with Tier 4 ISM DI Engine)\IC Instrument Cluster	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\SKID STEER LOADERS\SR175 / SV185 Series Skid Steer Loaders (with Tier 4 ISM DI Engine)\UCM Universal Control Module				✓		
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0003, S0004, S0005, S0006, S0007, S0008
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\CASE CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\VCM Vehicle Control/Display Module	✓	✓	✓	✓		
CASE\CASE CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ATC Instrument Cluster Unit	✓	✓	✓	✓		
CASE\CASE CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ECM Engine Control Module				✓	A0011, A0012, A0013, A0010, A0014	
CASE\CASE CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ENG Electronic Engine Control				✓		

CASE\CASE CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\JSC Joystick Steering Controller	✓			✓		
CASE\CASE CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\TECM Transmission Controller					A0011, A0012, A0013, A0014	
Engine Type\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
Engine Type\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
Engine Type\MS6.2	✓	✓	✓	✓	Please refer to NEWHOLLAND Function List	
Engine Type\Tier 3 NEF(EDC16C39)	✓	✓	✓	✓		

Special Function Table	
S0001	Engine injector code configuration(original screen with no vehicle controller backup)
S0002	Engine Restart Counter Reset/Unlock Inducement
S0003	Replacement of the Engine Oil/Filter - Reset Change Reminder
S0004	Replacement of the Exhaust Gas Recirculation Valve(EGR) - Reset ECU Data
S0005	Replacement of the Lambda Sensor - Reset ECU Data
S0006	Replacement of the Oxidant Catalyst(OxiCat) - Reset ECU Data
S0007	Replacement of the Particulate Filter(DPF/PM Catalyst) - Reset ECU Data
S0008	Replacement of the Rail Pressure Relief Valve(PRV) - Reset ECU Data
S0009	Replacement of the EGR Cooler - Reset ECU Data
S0010	Replacement of the Rail Pressure Sensor - Reset ECU Data
S0011	Replacement of the SCR Catalyst - Reset ECU Data
S0012	DPF Ash Cleaning Service - Reset ECU Data
S0013	Replacement of the Particulate Filter(DPF) - Reset ECU Data
S0014	Replacement of the Differential Pressure Sensor(Delta P) - Reset ECU Data

Active Test Table	
A0001	Compressor Air-Conditioner Relay
A0002	Injector Cut Out
A0003	Heated fuel filter relay
A0004	EOBD W/Light
A0005	Fuel Pump Relay
A0006	Cooling Fan Relay
A0007	Glow Plugs Activation Test
A0008	DPF Service Regeneration Test
A0009	Desulfurization/Thermal Conditioning Procedure
A0010	Engine - Urea Dosing System Test (UDST)
A0011	Engine - Urea Dosing Leakage Check (UDLC)
A0012	Engine - Urea Dosing Pump Check (UDPC) - SM with 12kg/h
A0013	Engine - Urea Dosing Pump Check (UDPC) - SM with 7.2kg/h
A0014	Engine - Urea Dosing Valve Check (UDVC)
A0015	CVT Transmission Hydrostatic Unit Test