

DEUTZ V13.09 Function List						
Note:						
✓	Functions marked with ✓ is fully supported.					
System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
EMR4\EDC17CV52	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0001, A0002, A0003, A0008, A0009, A0010, A0011	
EMR4\EDC17CV52MS	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0001, A0002, A0003, A0008, A0009, A0010, A0011	
EMR4\EDC17CV54	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0001, A0002, A0003, A0008, A0009, A0010, A0011	
EMR4\EDC17CV56	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0001, A0002, A0003, A0008, A0009, A0010, A0011	
EMR3\EDC16UC40	✓	✓	✓	✓	A0001, A0002, A0003	
EMR3\EDC7UC31	✓	✓	✓	✓	A0001, A0002, A0003	

Active Test Table	
A0001	Air filter differential pressure switch monitoring
A0002	Coolant level switch control
A0003	Water in fuel level control
A0004	Injector switch off
A0005	Fuel System overview
A0006	Exhaust gas recirculation throttle flap
A0007	Sensors
A0008	Engine Oil warning lamp
A0009	Input Test
A0010	Output Test
A0011	Fan Control