

WEICHAI V16.10 Function List

Note:

✓	Functions marked with ✓ is fully supported.
---	---

System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
Diesel Engine\China III Bosch EDC7\EDC7UC31 series universal version (k line)\Static diagnostic data	√	√	√	√	A0007, A0008, A0009, A0010	
Diesel Engine\China III Bosch EDC7\EDC7UC31 series universal version (k line)\Dynamic diagnostic data	√			√	A0001, A0002, A0003	S0016
Diesel Engine\China III Bosch EDC7\EDC7UC31 series dedicated version (k line)	√	√	√	√	A0004, A0005, A0006, A0004, A0079, A0080, A0003, A0081, A0038, A0082	S0018, S0030, S0017, S0004, S0016, S0015, S0017
Diesel Engine\China III Bosch EDC7\EDC7UC31 Series Dedicated Edition (CAN Line)	√	√	√	√		S0004, S0016, S0017, S0004, S0016, S0017, S0004, S0016, S0017, S0004, S0016, S0017, S0018, S0030
Diesel Engine\China III Bosch EDC7\EDC7 (J1939 CAN)		√	√	√		
Diesel Engine\Bosch	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai Bosch P949 China IV System_Kline	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai Bosch P949 China IV System_CAN (6/14)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai Bosch P949 China IV System_CAN (1/9)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai Bosch P949 EDC17CV44 with AdBlue (CAN)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai P949 EDC17CV44 with AdBlue (K)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai P949 Clear all historical fault codes (K)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P949 EDC17CV44 system\Weichai P949 Clear all historical trouble codes (CAN)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P1499_EDC17CV44 system\Weichai P1499_EDC17CV44 with AdBlue CAN	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P1499_EDC17CV44 system\Weichai P1499_EDC17CV44 with AdBlue K	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P1499_EDC17CV44 system\Weichai P1499 Clear all historical fault codes	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P1434 EDC17CV41 Special Beijing V (Bosch)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai P1434 EDC17CV41 Special Beijing V (Weichai)	√	√	√	√	Please refer to BOSCH Function List	
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power Automatic Identification	√	√	√	√		
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power 24V Guosi (WP2.1 WP3_24V)	√	√	√	√	A0005, A0083, A0003, A0011, A0015, A0017, A0019, A0012, A0013, A0014, A0020, A0021, A0023, A0022	S0031, S0032, S0033, S0034, S0035, S0036, S0037, S0038, S0039, S0040, S0041, S0003, S0042, S0035, S0036, S0037, S0038, S0039, S0040, S0041
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power Common Rail 485, 490, 4102, 4105, 4108 China IV	√	√	√	√	A0011, A0005, A0006, A0003, A0080, A0015, A0016, A0018, A0084, A0085, A0086, A0087, A0088, A0089, A0090, A0017, A0019, A0012, A0013, A0014, A0020,	S0031, S0032, S0033, S0034, S0003, S0042
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power 24V China V	√	√	√	√	A0005, A0006, A0003, A0080, A0084, A0085, A0086, A0087, A0088, A0089, A0090	
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power 12V China IV (Engine: WP2.1)	√	√	√	√		
Diesel Engine\China IV/V Bosch EDC17\Weichai Power\Weichai Power 12V China V (EDC17C81)	√	√	√	√		
Diesel Engine\Weichai Autonomous WISE Automatic Identification	√	√	√	√	A0104, A0214, A0215, A0216, A0217, A0218, A0219, A0220, A0221, A0222, A0223, A0224, A0225, A0103, A0226, A0227, A0228, A0229, A0230, A0231, A0232,	S0049, S0045, S0056, S0046, S0050, S0054, S0055, S0057, S0058, S0017, S0061, S0043, S0062, S0052, S0053, S0059, S0060, S0051
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai self-identification of WISE (old version)	√	√	√	√	A0104, A0106, A0108, A0125, A0126, A0110, A0111, A0127, A0128, A0129, A0130, A0100, A0107, A0131, A0091, A0132, A0133, A0134, A0135, A0136, A0137,	S0043, S0048, S0014, S0015, S0017
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE15 (Non-Road T3, China IV, V) (Part No. 612650080075, 3310010013138)	√	√	√	√	A0033, A0034, A0035, A0036, A0037, A0038, A0039, A0040, A0041, A0042	S0014, S0015
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE15C (Non-Road T4, China IV, V) (Part No. 1001228607)	√	√	√	√	A0183, A0184, A0185, A0186, A0187, A0122, A0188, A0147, A0189, A0042, A0109, A0110, A0111, A0041	S0043, S0017, S0017, S0017, S0017, S0017
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE12A (Part Number 1000430716)	√	√	√	√	A0191, A0164, A0161, A0192, A0193, A0194, A0195, A0133, A0181, A0196, A0197	
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE12B	√		√	√		
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE10A (China VI MD1)	√	√	√	√	A0004, A0096, A0097, A0098, A0091, A0099, A0100, A0101, A0102, A0103, A0104, A0105, A0106, A0034, A0107, A0108, A0109, A0110, A0111, A0112, A0113,	S0043, S0043, S0043, S0043, S0043, S0043, S0043, S0043, S0044, S0044, S0044, S0044, S0044, S0044, S0045,
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE10B	√	√	√	√	A0104, A0106, A0108, A0125, A0126, A0110, A0111, A0127, A0128, A0129, A0130, A0100, A0107, A0131, A0091, A0132, A0133, A0134, A0135, A0136, A0137,	S0043
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE13A (China V/VI)	√	√	√	√	A0190, A0097, A0102, A0105, A0146, A0125, A0126, A0149, A0150, A0156	S0043, S0043, S0043, S0043, S0043, S0043, S0043, S0043, S0048, S0048, S0048, S0048, S0048, S0048, S0048,

Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE13C	✓	✓	✓	✓		S0043, S0048
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE13D	✓	✓	✓	✓		S0043, S0048
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai's Autonomous WISEC15 (WP17V8 model) (part number 612650080075)	✓	✓	✓	✓	A0033, A0034, A0035, A0036, A0037, A0038, A0039, A0040, A0041, A0042	
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE70	✓	✓	✓	✓		
Diesel Engine\Weichai Autonomous WISE (old version)\Weichai Autonomous WISE18A	✓	✓	✓	✓	A0033, A0034, A0035, A0036, A0037, A0038, A0039, A0040, A0041, A0198	
Diesel Engine\VE Pump\VE Pump (Longkou)	✓	✓	✓	✓		
Diesel Engine\VE Pump\VE Pump (Nanjing)		✓	✓	✓		
Natural Gas Engine\Bosch EGC4	✓	✓	✓	✓	A0091, A0092, A0093, A0094, A0095	
Natural Gas Engine\Independent WNG	✓	✓	✓	✓		
Natural Gas Engine\Woodward OH6.0	✓	✓	✓	✓	A0052, A0053, A0054, A0055, A0056, A0057, A0058, A0059, A0060, A0061, A0062, A0063, A0064, A0065, A0066, A0067, A0068, A0069, A0070, A0071, A0072, A0066, A0067, A0068, A0069, A0070, A0071, A0072,	S0019, S0020, S0021, S0022, S0023, S0024, S0025, S0026, S0027, S0028, S0029
Natural Gas Engine\Woodward OH6.0 China VI	✓	✓	✓	✓	A0043, A0044, A0045, A0046, A0047, A0048, A0049, A0050, A0051, A0009	
Natural Gas Engine\Woodward OH2.0	✓	✓	✓	✓	Please refer to NATURALGASENGINE Function List	
Natural Gas Engine\WISE11 (Road China VI Gas) (1001419750 (IGBT) -1001419752 (Smart))	✓	✓	✓	✓	A0253, A0233, A0234, A0235, A0236, A0226, A0227, A0228, A0229, A0230, A0252, A0214, A0216, A0217, A0218, A0219, A0306, A0307, A0308, A0309, A0310,	S0017, S0065, S0066, S0067, S0068, S0054, S0069, S0070, S0057
Natural Gas Engine\WISE17 (Road China V Gas) (612600191742)	✓	✓	✓	✓	A0164, A0165, A0016, A0166, A0167, A0168, A0169, A0170, A0171, A0172, A0173, A0174, A0175, A0176, A0177, A0178	
Natural Gas Engine\WNG (road China V gas)	✓	✓	✓	✓	A0179, A0034, A0035, A0180, A0037, A0038, A0039, A0181, A0041, A0182	
Natural Gas Engine\Weichai EControls	✓	✓	✓	✓		
Exhaust Aftertreatment	✓	✓	✓	✓	Please refer to SCR Function List	
New energy controller\Weichai New Energy GVCU	✓	✓	✓	✓		
New energy controller\Yaxing New Energy VMU	✓	✓	✓	✓		
New energy controller\Weichai WISEPLUS	✓	✓	✓	✓		
New energy controller\Weichai Autonomous WISE70	✓	✓	✓	✓		
New energy controller\PSI gasoline engine		✓	✓	✓		
New energy controller\Geely Controller	✓	✓	✓	✓		
New energy controller\WISE13M	✓	✓	✓	✓		
New energy controller\WISE42	✓	✓	✓	✓		
Yashang Intelligent Components Diagnosis\Gasoline engine controller (MT22.1)	✓	✓	✓	✓		
Yashang Intelligent Components Diagnosis\Yashang Airbag	✓	✓	✓	✓		
Yashang Intelligent Components Diagnosis\Rotation sensor (SAS)						S0063, S0064
Yashang Intelligent Components Diagnosis\Anti-lock braking system\Yashang DBC1200-ABS	✓	✓	✓	✓		
Yashang Intelligent Components Diagnosis\Anti-lock braking system\ESC1	✓	✓	✓	✓	A0199, A0200, A0201, A0202, A0203, A0204, A0205, A0206, A0207, A0208, A0209, A0210, A0211, A0212, A0213	
Yashang Intelligent Components Diagnosis\Anti-lock braking system\Kormee - ABS	✓	✓	✓	✓	Please refer to ABS Function List	

Special Function Table	
S0001	Cylinder cut off (injection off) test
S0002	Engine speed comparison
S0003	Start fault information test
S0004	Compression Test
S0005	Clear PRV valve timeout
S0006	Clear PRV valve timeout
S0007	Write a new VIN
S0008	Clear Aftertreatment DTCs
S0009	Forced clear fault Code

S0010	Small injection rate and small injection quantity test
S0011	Medium injection rate and medium injection quantity test
S0012	Large injection rate and large injection quantity test
S0013	Exhaust aftertreatment system test
S0014	Cylinder Cut Off Test
S0015	PRV valve
S0016	Startup fault information
S0017	Cylinder Cut Off Test
S0018	High-pressure Test
S0019	Write VIN
S0020	Engine serial number
S0021	Engine speed setting
S0022	HEGO sensor diagnosis allows use
S0023	Allowable use of catalyst sensor diagnosis
S0024	DYNO mode diagnosis allows use
S0025	Exhaust pressure relief valve control test
S0026	Throttle cleaning
S0027	PTO speed reference
S0028	Speed control conversion
S0029	Service diagnostics allow use
S0030	Accelerated Testing
S0031	Cylinder cut off test (6 cylinder)
S0032	Cylinder cut off test (4 cylinder)
S0033	Rotational speed comparison (6 cylinders)
S0034	Rotational speed comparison (4 cylinders)
S0035	Exhaust Brake
S0036	Air conditioning switch request
S0037	Idle speed tuning
S0038	Maximum Vehicle Speed Limit
S0039	VIN Number
S0040	Vehicle data number
S0041	Vehicle model
S0042	Nozzle data
S0043	AdBlue injection test
S0044	DPF parking regeneration (it takes about 1 hour)
S0045	New car's off-line exhaust pipe tightness test
S0046	DPM system test
S0047	DPF parking regeneration (P201-V176 version)
S0048	DPF parking regeneration
S0049	Urea injection function
S0050	DPF Parking Regeneration Test
S0051	PRV valve reset
S0052	Three-speed fan diagnostic test
S0053	DPF regeneration test
S0054	Ready state
S0055	Vehicle inspection and testing
S0056	Upstream Nitrogen Oxygen Sensor Fault Diagnosis
S0057	EGR position test
S0058	Intake throttle valve position test
S0059	Injector IQA code correction
S0060	SCR Injection Readiness Test
S0061	Throttle position test
S0062	SCR injection function
S0063	Angle sensor (SAS) reading
S0064	SAS zero calibration
S0065	Gas injection valve cleaning
S0066	Wide-range oxygen sensor correction test
S0067	OEM variable
S0068	Vehicle VIN code update
S0069	Wide-range oxygen sensor BurnOff
S0070	Electronic Throttle Test

Active Test Table

A0001	Engine brake Exhaust throttle valve
A0002	Fault lamp
A0003	Cold Startup Lamp
A0004	Air conditioning relay
A0005	OBd lamp
A0006	Flashing light
A0007	High-pressure Test
A0008	Accelerated Testing
A0009	Cylinder Cut Off Test
A0010	Compression Test
A0011	A/C compressor
A0012	Booster actuator
A0013	Exhaust gas recirculation actuator
A0014	Engine speed test
A0015	Preheat indicator light test
A0016	Fault light test
A0017	Fuel metering actuator test
A0018	System light test
A0019	Throttle actuator test
A0020	Variable Vortex Actuator Test
A0021	Alternative rail voltage seted-point signal testing
A0022	External test value
A0023	Selected cylinder injection status test
A0024	SCR injection valve
A0025	SCR-heating pressure curve

A0026	SCR-AdBlue tank heating
A0027	AdBlue supply pump
A0028	AdBlue 4/2 access valve
A0029	SCR heating reflow curve
A0030	AdBlue heating supply module
A0031	AdBlue heat pumping curve
A0032	External AdBlue heating relay
A0033	AC relay
A0034	Intake heating relay 1
A0035	Intake heating relay 2
A0036	Intake heating lamp
A0037	OBD fault lamp
A0038	Warning lights
A0039	Error light
A0040	Speed substitution
A0041	Rail pressure replacement
A0042	Oil metering unit
A0043	Throttle
A0044	Exhaust bypass valve test
A0045	Nozzle cleaning
A0046	Exhaust Brake
A0047	Ignition and nozzle
A0048	Oxygen sensor test
A0049	Self-learning table clear function
A0050	Throttle cleaning
A0051	Oxygen sensor BurnOff function
A0052	Engine fault indicator lamp
A0053	Overheat indicator
A0054	Lock Up
A0055	Generator prohibited
A0056	Engine test lamp
A0057	Engine brake
A0058	RSG Cruise PTO
A0059	Fuel Low Indicator Light
A0060	Starter control
A0061	Cooling Fan1
A0062	Cooling Fan2
A0063	fuel level gauge
A0064	EGR valve system
A0065	Engine Stop Indicator Light
A0066	Close Spark 1
A0067	Close Spark 2
A0068	Close Spark 3
A0069	Close Spark 4
A0070	Close Spark 5
A0071	Close Spark 6
A0072	Door injector 1
A0073	Door injector 2
A0074	Door injector 3
A0075	Door injector 4
A0076	Door injector 5
A0077	Door injector 6
A0078	ECU reset
A0079	Diagnostic lights
A0080	Intake heating relay
A0081	Water in oil lamp
A0082	Exhaust brake solenoid valve
A0083	Flash
A0084	Pressure line heating
A0085	Inlet pipe heating
A0086	Return line heating
A0087	AdBlue pump heating
A0088	AdBlue pump steering valve
A0089	AdBlue tank heating solenoid valve
A0090	AdBlue heating relay
A0091	MIL lamp signal test
A0092	SYS lamp signal test
A0093	Throttle Actuator Test
A0094	Tank 1- low pressure globe valve
A0095	Tank 1- high pressure stop valve
A0096	Electronically controlled bleed valve
A0097	EGR position test
A0098	Cold start light test
A0099	MeUn valve test
A0100	Diesel pre-charge pump test
A0101	SVS lamp
A0102	Throttle position test
A0103	Rail pressure set value substitute value test
A0104	Close path service test
A0105	VGt test
A0106	Exhaust Butterfly Valve
A0107	Fuel Heating Test
A0108	Starter Relay
A0109	Fan PWM drive
A0110	Fan digital drive pin 1
A0111	Fan digital drive pin 2
A0112	HC injection metering valve drive relay
A0113	AdBlue return tube heating relay test
A0114	AdBlue pressure tube heating relay
A0115	AdBlue pipette heating relay

A0116	AdBlue pump heating relay
A0117	AdBlue pump drive
A0118	Reverse valve drive
A0119	AdBlue nozzle drive
A0120	Aftertreatment heating main relay
A0121	HC Injection shut-off valve test
A0122	Alarm lamp (WarningLamp)
A0123	Stop light
A0124	NCD light
A0125	Intake heating relay 1 test
A0126	Fan PWM drive test
A0127	Disable delayed stop test
A0128	MeUn valve duty test
A0129	MeUn valve flow test
A0130	MeUn valve current test
A0131	Rail pressure set substitute value test
A0132	SVS lamp signal test
A0133	Alarm lamp test
A0134	Stop lamp test
A0135	NCD lamp test
A0136	Electronically controlled oil pump
A0137	holsetvgt control opening test
A0138	EGR position self-learning test
A0139	Throttle position self-learning test
A0140	Engine Oil filter maintenance indicator test
A0141	Fuel filter service indicator test
A0142	Engine oil Pressure Indicator
A0143	Water in oil indicator
A0144	Air conditioning relay actuator
A0145	PCV valve test
A0146	Exhaust Butterfly valve test
A0147	Intake heating relay 1 (AirHt1)
A0148	Start Relay Test
A0149	Fan digital drive pin 1 test
A0150	Fan digital drive pin 2 test
A0151	HC injection metering valve drive relay test
A0152	AdBlue pressure tube heating relay test
A0153	AdBlue pipette heating relay test
A0154	AdBlue pump heating relay test
A0155	AdBlue tank heating solenoid valve test
A0156	AdBlue Pump Drive Test
A0157	Reverse valve drive test
A0158	AdBlue nozzle drive test
A0159	Aftertreatment heating main relay test
A0160	Alarm light (WarningLamp) test
A0161	Cold start lamp test
A0162	air system relay test
A0163	Dual fuel warning light test
A0164	Engine speed control test
A0165	MIL lamp test
A0166	Silicone Fan Test
A0167	Low pressure off Valve check test
A0168	Three-speed fan 1 test
A0169	Three-speed fan 2 test
A0170	oxygen sensor heating test
A0171	Ignition coil 1 test
A0172	ignition coil 2 test
A0173	Ignition coil 3 test
A0174	Ignition coil 4 test
A0175	Ignition coil 5 test
A0176	Ignition Coil 6 Test
A0177	Exhaust bypass valve test
A0178	Surge valve test
A0179	Engine speed substitute
A0180	Intake heating lamp (cold start light)
A0181	Engine closing path test
A0182	A/C relay
A0183	Air conditioning compressor relay control (ACCD)
A0184	Speed setting value (EngM)
A0185	Intake heating lamp (cold start lamp) control (CSLPCD)
A0186	OBD fault light (MILAMP)
A0187	Error light (ErrLmp)
A0188	Engine closing path (stShutOff)
A0189	Intake heating relay 2 (AirHt2)
A0190	Electronically controlled deflation Valve test
A0191	Air conditioner compressor relay test
A0192	OBD lamp test
A0193	Oil metering unit test
A0194	Error lamp test
A0195	Rail pressure value test
A0196	Heating relay 1 test
A0197	Heating relay 2 test
A0198	Engine shutdown path control
A0199	System enable relay control command
A0200	Red warning light control command
A0201	ABS (anti-lock braking system) warning light control command
A0202	Enable solenoid valve PWM (pulse width modulation) control command
A0203	Pump motor control instructions
A0204	Enable solenoid valve ON-Off control command
A0205	Right rear release solenoid valve ON-Off control command

A0206	Right rear acting solenoid valve ON-Off control command
A0207	Left rear release solenoid valve ON-Off control command
A0208	Left rear acting solenoid valve ON-Off control command
A0209	Right front release solenoid valve ON-Off control command
A0210	Right front acting solenoid valve ON-Off control command
A0211	Left front release solenoid valve ON-Off control command
A0212	Left front acting solenoid valve ON-Off control command
A0213	Bad road conditions PWM (pulse width modulation) duty cycle command
A0214	Exhaust Butterfly Valve Actuator Test
A0215	Air intake heating relay 1 actuator test
A0216	Start relay actuator test
A0217	Fan PWM Drive Actuator Test
A0218	Fan digital drive pin 1 actuator test
A0219	Fan digital drive pin 2 actuator test
A0220	Prohibit delay stop actuator test
A0221	MeUn Valve Duty Cycle Actuator Test
A0222	MeUn Valve Flow Actuator Test
A0223	MeUn valve current actuator test
A0224	Diesel pre-charge pump actuator test
A0225	Fuel heating actuator test
A0226	MIL lamp actuator test
A0227	SVS lamp actuator test
A0228	Warning light actuator test
A0229	Stop Light Actuator Test
A0230	NCD lamp perform test
A0231	Electronic Control Oil Pump Actuator Test
A0232	holset vgt control opening actuator test
A0233	EGR position actuator test
A0234	Throttle position actuator test
A0235	EGR position self-learning actuator test
A0236	Throttle position self-learning actuator test
A0237	Engine oil filter service indicator light actuator test
A0238	Fuel Filter Service Indicator Light Actuator Test
A0239	Engine oil Pressure Indicator Light Actuator Test
A0240	Water in oil indicator light actuator test
A0241	HC injection metering valve drive actuator test
A0242	AdBlue return tube heating relay actuator test
A0243	AdBlue pressure tube heating relay actuator test
A0244	AdBlue pipette heating relay actuator test
A0245	Urea pump heating relay actuator test
A0246	AdBlue tank heating solenoid valve actuator test
A0247	AdBlue pump drive actuator test
A0248	Reverse Valve Actuator Test
A0249	AdBlue nozzle drive actuator test
A0250	HC Injection Shutoff Valve Actuator Test
A0251	Aftertreatment heating main relay actuator test
A0252	Air conditioning relay actuator test
A0253	Electronically controlled bleed valve actuator test
A0254	MeUn valve actuator test
A0255	PCV Valve Actuator Test
A0256	Cold start lamp actuator test
A0257	VGT Actuator Test
A0258	Air System Actuator Relay Test
A0259	Dual Fuel Warning Light Actuator Test
A0260	VGT Actuator Test 1
A0261	VGT Actuator Test 2
A0262	Delayed stop actuator test
A0263	Engine Normal Operation Relay Diagnosis Actuator Test
A0264	PCV valve current actuator test
A0265	Intake Heating Relay 2 Actuator Test
A0266	Override indicator light actuator test
A0267	Starter relay 2 actuator test
A0268	PCV Valve Duty Cycle Actuator Test
A0269	Pump Actuator Test
A0270	RTT valve actuator test
A0271	RTT valve NO channel electronic pump actuator test
A0272	RTT valve NC channel electronic pump actuator test
A0273	No.1 LNG pump Extend solenoid valve actuator test
A0274	No.2 LNG pump Extend solenoid valve actuator test
A0275	Tank 1 TSV valve actuator test
A0276	No. 2 Tank TSV Valve Actuator Test
A0277	Bypass valve actuator test
A0278	Level gauge power supply relay actuator test
A0279	GSO Valve Actuator Test
A0280	Service Mode Light Actuator Test
A0281	HPDI Mode Lamp Actuator Test
A0282	Intake Heating Relay Actuator Test
A0283	Drain valve actuator test
A0284	Electronic Control Booster Actuator Test
A0285	Starter relay 1 actuator test
A0286	Intake heating lamp (cold start lamp)
A0287	Speed setpoint
A0288	Oil metering unit (MeUn)
A0289	Oil metering unit test
A0290	Intake heating relay 2 (AirHt1)
A0291	Air conditioning compressor relay control
A0292	Speed Control Actuator Test
A0293	Jet Release Substitute Value Test
A0294	Urine Flooding Pump Drive Actuator Test
A0295	Smart Supercharger Actuator Test

A0296	Wrning Lamp Control (WrnLmp)
A0297	Intake Heating Relay 1 (AirHt1)
A0298	STOP Lamp Control (StopLmp)
A0299	Engine closing path
A0300	Intake Heating Lamp (Cold Start Lamp) (CSLPCD)
A0301	Rail Pressure Substitution (pRailSetSubst)
A0302	Intake heating relay 1 (AirHt1)
A0303	Intake heating relay 2 (AirHt2)
A0304	Electric booster valve actuator test
A0305	Intelligent booster actuator test
A0306	Ignition angle actuator test
A0307	lambda executor test
A0308	High pressure shut-off valve actuator testing
A0309	Low Pressure Shutoff Valve Actuator Testing
A0310	In-cylinder brake butterfly valve 1 actuator test
A0311	In-cylinder brake butterfly valve 2 actuator test
A0312	Surge Valve Actuator Testing
A0313	Engine speed output actuator test
A0314	High water temperature fault light actuator test
A0315	In-cylinder brake valve 1 actuator test
A0316	In-cylinder brake valve 2 actuator test
A0317	Exhaust disc valve actuator test
A0318	Engine speed output duty cycle actuator test
A0319	Throttle duty cycle actuator test
A0320	Overload operation alarm light actuator test
A0321	Duty cycle actuator test of intake bypass valve
A0322	NGK wide oxygen sensor relay drive actuator test
A0323	PFAV valve actuator testing
A0324	Trim valve actuator testing
A0325	PFAV Lock Off valve actuator test
A0326	PFAV position self-learning actuator testing
A0327	Electric control vent valve duty cycle actuator test
A0328	SFI low pressure cut-off valve actuator test
A0329	Noron Electric Control Release Valve actuator test