



JCB V12.1 Function list

Note:

✓ Functions marked with ✓ is fully supported.

System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
Construction\Articulated Dump Trucks	✓	✓	✓	✓		
Construction\Backhoe Loaders\Backhoe Loader 3DX Series India	✓	✓	✓	✓		
Construction\Backhoe Loaders\Backhoe Loaders\Immobiliser Diagnostics		✓	✓			
Construction\Backhoe Loaders\Backhoe Loaders\LiveLink Diagnostics	✓	✓	✓			
Construction\Backhoe Loaders\Backhoe Loaders\Machine Diagnostics	✓	✓	✓	✓		
Construction\Backhoe Loaders\Compact Backhoe Loaders	✓	✓	✓	✓		
Construction\Compact Excavators (Mini / Midi)	✓	✓	✓	✓		
Construction\Excavators	✓	✓	✓	✓		
Construction\Rough Terrain Forklifts	✓	✓	✓	✓		
Construction\Site Dumpers	✓	✓	✓	✓		
Construction\Telemasters	✓	✓	✓	✓		
Construction\Telescopic Handlers	✓	✓	✓	✓		
Construction\Teletruks	✓	✓	✓	✓		
Construction\Vibratory Compactors	✓	✓	✓	✓		
Construction\Wheeled Loading Shovels	✓	✓	✓	✓		
Agricultural\Fastrac Tractors\2000-3000		✓	✓	✓		
Agricultural\Fastrac Tractors\3000 Series 2	✓	✓	✓	✓		
Agricultural\Fastrac Tractors\3000 Series 3	✓			✓		
Agricultural\Fastrac Tractors\3000 Series 4	✓			✓		
Agricultural\Fastrac Tractors\4000 Series	✓			✓		
Agricultural\Fastrac Tractors\7000 Series	✓	✓	✓	✓		
Agricultural\Fastrac Tractors\8000 Series 3	✓	✓	✓	✓		
Agricultural\Fastrac Tractors\8000 Series 4	✓			✓		
Agricultural\Fastrac Tractors\8250 Series 2	✓	✓	✓	✓		
Agricultural\Telemasters\TM220	✓	✓	✓	✓		
Agricultural\Telemasters\TM320 T4i	✓	✓	✓	✓		

Agricultural\Telemasters\TM320 Tier 4 Final Mk 1	✓	✓	✓	✓		
Agricultural\Telemasters\TM420 Tier 4 Final	✓	✓	✓	✓		
Agricultural\Telescopic Handlers\2007+	✓	✓	✓	✓		
Agricultural\Telescopic Handlers\525-60 Compact Loadall	✓	✓	✓	✓		
Agricultural\Telescopic Handlers\Tier 4	✓	✓	✓	✓		
Agricultural\Wheeled Loading Shovels\Compact	✓	✓	✓	✓		
Agricultural\Wheeled Loading Shovels\Large	✓	✓	✓	✓		
Agricultural\Wheeled Loading Shovels\Medium	✓	✓	✓	✓		
Agricultural\Wheeled Loading Shovels\Telemasters	✓	✓	✓	✓		
Waste\Telescopic Handlers\Tier 3	✓	✓	✓	✓		
Waste\Telescopic Handlers\Tier 4	✓	✓	✓	✓		
Waste\Wheeled Loading Shovels\427/437/435S T4F	✓	✓	✓	✓		
Waste\Wheeled Loading Shovels\457 T4F	✓	✓	✓	✓		
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax Engine\JCB Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004

Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax Engine (IPU)\JCB Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax Engine (OEM Base)\JCB Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax Engine (G-Drive)\JCB Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001

Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine\JCB Ecomax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Ecomax Engine\JCB Ecomax Engine Setup\Injector Calibration						0008
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Ecomax Engine (IPU)\JCB Ecomax Engine Setup\Injector Calibration						0008
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007

Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Ecomax Engine (OEM Base)\JCB Ecomax Engine Setup\Injector Calibration						0008
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Ecomax Engine (G Drive)\JCB Ecomax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax 672 Engine\JCB P672 Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004

Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax 672 Engine (IPU)\JCB P672 Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax 672 Engine (OEM Base)\JCB P672 Dieselmax Engine Setup\Injector Calibration						0008
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\JCB Dieselmax 672 Engine (G Drive)\JCB P672 Dieselmax Engine Setup\Injector Calibration						0008

Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier II/ Tier III	✓	✓	✓	✓	✓	0001
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier 3 Equiv 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier 3 Equiv 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier II 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier III 6 cylinder	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier IVi 55kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier IVi 56+kW	✓	✓	✓	✓	✓	0002, 0003, 0004
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier IV Final 55kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\Tier IV Final 56+kW					✓	0002, 0003, 0004, 0005, 0006, 0007
Engines\430 Dieselmax Engine\430 Dieselmax Engine Diagnostics\430 55kW					✓	0002, 0003
Engines\430 Dieselmax Engine\430 Dieselmax Engine Setup\Injector Calibration						0008
Engines\Kohler TCR Engine\Kohler TCR Engine Diagnostics\Kohler 3 Cyl		✓	✓	✓	✓	
Engines\Kohler TCR Engine\Kohler TCR Engine Diagnostics\Kohler 4 Cyl		✓	✓	✓	✓	
Engines\Kohler TCR Engine\Kohler TCR Engine Setup\Injector Calibration						0008

Special Function Table	
0001	High Pressure Fuel Diagnostics
0002	Fuel System Diagnostics Test – Cranking
0003	Fuel System Diagnostic Test – Engine Running
0004	Fuel System Diagnostics
0005	Aftertreatment Service Routines
0006	Aftertreatment component initialisation
0007	Aftertreatment Component Test
0008	Injector Calibration