

Bendix V12.84 Function List

Note:

✓ Functions marked with ✓ is fully supported.

| System | ECU Info | Read Fault Code | Clear Fault Code | Live Data | Active Test | Special Func |
|--|----------|-----------------|------------------|-----------|--|---------------------|
| Green 9PIN/VOLVO OBD16\A18 | ✓ | ✓ | ✓ | ✓ | A0001, A0002, A0003, A0004 | S0001 |
| Green 9PIN/VOLVO OBD16\ABS U1x | ✓ | ✓ | ✓ | ✓ | A0003, A0001, A0005, A0004, A0002 | S0002 |
| Green 9PIN/VOLVO OBD16\ABS2x | ✓ | ✓ | ✓ | ✓ | A0003, A0001, A0005, A0004, A0002 | S0001, S0003 |
| Green 9PIN/VOLVO OBD16\AutoVue3G | ✓ | ✓ | ✓ | | A0006, A0007 | S0003 |
| Green 9PIN/VOLVO OBD16\EC-17 | ✓ | ✓ | ✓ | | | S0003, S0001 |
| Green 9PIN/VOLVO OBD16\EC-30 | ✓ | ✓ | ✓ | ✓ | A0008 | S0001 |
| Green 9PIN/VOLVO OBD16\EC-30T | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\EC-60 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0010, A0004, A0002, A0011 | S0001, S0004, S0005 |
| Green 9PIN/VOLVO OBD16\EC-80 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0010, A0004, A0002 | S0001, S0004, S0005 |
| Green 9PIN/VOLVO OBD16\FLC20 | ✓ | ✓ | ✓ | | | S0006 |
| Green 9PIN/VOLVO OBD16\MC-30 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0002 | S0001 |
| Green 9PIN/VOLVO OBD16\SDP | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\TABS6 | ✓ | | | ✓ | A0003, A0009, A0004, A0002 | S0001 |
| Green 9PIN/VOLVO OBD16\TABS6 MV | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\TABS6 MV MC | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\TABS6 Advanced 5v CAN | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\TABS6 Adv MC 5v CAN | ✓ | ✓ | ✓ | ✓ | | |
| Green 9PIN/VOLVO OBD16\Tractor Lift Axle ABS | ✓ | | | ✓ | A0003, A0009, A0004, A0002 | S0001 |
| Green 9PIN/VOLVO OBD16\VORAD VS400/DIU\DIU | ✓ | ✓ | ✓ | | | |
| Green 9PIN/VOLVO OBD16\VORAD VS400/DIU\FLR | ✓ | ✓ | ✓ | | | |
| Green 9PIN/VOLVO OBD16\VS500 | ✓ | ✓ | ✓ | | | |
| Green 9PIN/VOLVO OBD16\Wingman | ✓ | ✓ | ✓ | | | |
| General OBD16/DIESEL 6&9PIN/0thers\A18 | ✓ | ✓ | ✓ | ✓ | A0001, A0002, A0003, A0004 | S0001 |
| General OBD16/DIESEL 6&9PIN/0thers\ABS U1x | ✓ | ✓ | ✓ | ✓ | A0003, A0001, A0005, A0004, A0002 | S0002 |
| General OBD16/DIESEL 6&9PIN/0thers\ABS2x | ✓ | ✓ | ✓ | ✓ | A0003, A0001, A0005, A0004, A0002 | S0001, S0003 |
| General OBD16/DIESEL 6&9PIN/0thers\AutoVue3G | ✓ | ✓ | ✓ | | A0006, A0007 | S0003 |
| General OBD16/DIESEL 6&9PIN/0thers\EC-17 | ✓ | ✓ | ✓ | | | S0003, S0001 |
| General OBD16/DIESEL 6&9PIN/0thers\EC-30 | ✓ | ✓ | ✓ | ✓ | A0008 | S0001 |
| General OBD16/DIESEL 6&9PIN/0thers\EC-30T | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/0thers\EC-60 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0010, A0004, A0002, A0011 | S0001, S0004, S0005 |
| General OBD16/DIESEL 6&9PIN/0thers\EC-80 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0010, A0004, A0002 | S0001, S0004, S0005 |
| General OBD16/DIESEL 6&9PIN/0thers\FLC20 | ✓ | ✓ | ✓ | | | S0006 |
| General OBD16/DIESEL 6&9PIN/0thers\MC-30 | ✓ | ✓ | ✓ | ✓ | A0003, A0009, A0002 | S0001 |

| | | | | | | |
|--|---|---|---|---|----------------------------|-------|
| General OBD16/DIESEL 6&9PIN/Others\SDP | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/Others\TABS6 | ✓ | | | ✓ | A0003, A0009, A0004, A0002 | S0001 |
| General OBD16/DIESEL 6&9PIN/Others\TABS6 MV | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/Others\TABS6 MV MC | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/Others\TABS6 Advanced 5v CAN | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/Others\TABS6 Adv MC 5v CAN | ✓ | ✓ | ✓ | ✓ | | |
| General OBD16/DIESEL 6&9PIN/Others\Tractor Lift Axle ABS | ✓ | | | ✓ | A0003, A0009, A0004, A0002 | S0001 |
| General OBD16/DIESEL 6&9PIN/Others\VORAD VS400/DIU\DIU | ✓ | ✓ | ✓ | | | |
| General OBD16/DIESEL 6&9PIN/Others\VORAD VS400/DIU\FLR | ✓ | ✓ | ✓ | | | |
| General OBD16/DIESEL 6&9PIN/Others\VS500 | ✓ | ✓ | ✓ | | | |
| General OBD16/DIESEL 6&9PIN/Others\Wingman | ✓ | ✓ | ✓ | | | |

| Special Function Table | |
|------------------------|--------------------------|
| S0001 | Reset ABS Controller |
| S0002 | Tire Size |
| S0003 | Controller Configuration |
| S0004 | Dyno Mode |
| S0005 | Calibrate ESP Sensors |
| S0006 | SPTAC Calibration |

| Active Test Table | |
|-------------------|------------------|
| A0001 | Lamp |
| A0002 | Miscellaneous |
| A0003 | Modulators |
| A0004 | Sensors |
| A0005 | Switch |
| A0006 | Clear Event Log |
| A0007 | Clear Videos |
| A0008 | Test |
| A0009 | Lamps |
| A0010 | Switches |
| A0011 | Stability System |