



# CASE V13.0 Function List

**Note:**

✓	Functions marked with ✓ is fully supported.					
System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx)\ADIC Analog/Digital Inst Cluster	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx)\GA Power Take-Off Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Maxxum Series Tractor(with 12x12 Transmission)(Tier 3)(ZxBExxxxx)\Steer Steering Controller	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\ACM Armrest Control Module	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\ACT Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\ECM Engine Control Module				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\EDC Electronic Draft Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\EPL Electronic Park Lock	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\FEHR Front Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\ICP Integrated Control Panel	✓			✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\RPTO Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\TCU Tractor Control Unit	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Models 180, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZDRH00901 – ZDRH00915, ZERH02500 – ZERH08000)\Trans Transmission Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ECM Engine Control Module				✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Trans Transmission Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\RPTO Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\4WD 4WD Diff Lock Control		✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\SSS Secondary Steering System	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ACT Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\Hitch Electronic Hitch Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\FHC Front Hitch Control		✓	✓			
CASE\CASE IH AG\TRACTORS\Magnum Tractor (Tier 4B / Tier 2B – Models 250, 280, 310, 340) (with Full Power Shift) (Tier 3 – Models 2654, 3154) (P. I. N. ZDRF00801 and Above)\ICP Integrated Control Panel				✓		

CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\4WD 4WD Diff Lock Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\ACM Armrest Control Module	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\ATC Auto Temperature Controller	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\ECM Engine Control Module				✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\EDC Electronic Draft Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\ENG Electronic Engine Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\EPL Electronic Park Lock	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\FEHR Front Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\ICP Integrated Control Panel	✓			✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\Inst Tractor Monitor	✓	✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\REHR Rear Hydraulic Remote		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\RPTD Rear PTO Control		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\SFA Suspension Front Axle		✓	✓	✓		
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\TCU Tractor Control Unit	✓	✓	✓			
CASE\CASE IH AG\TRACTORS\Puma Series Tractor (Models 185, 200, 220, 240) (with CVT Transmission) (Tier 4B) (P. I. N. ZxES00001 - ZxES99999)\Trans Transmission Control		✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\Tier 4 F5C (EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0003, S0004, S0005, S0006, S0007, S0008
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 570N EP, 580N EP) (Tier 4B)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\Tier 4 F5C (EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\ECM Engine Control Module				✓	A0007, A0009, A0010	S0002, S0009, S0004, S0006, S0008, S0010, S0011
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 580ST, 590ST, 590SN, 695ST) (Tier 4B Engine with SCR)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\Tier 4 F5C (EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N, 580SN, 580SNWT, 590SN, 570NXT) (Tier 4A)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\Tier 3 NEF (EDC7UC31)	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\Eng Engine Controller				✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N > NFC719059, 580SN > NFC722013, 580SNWT > NFC723500, 590SN > NFC725011) (Tier 3)\VCM Vehicle Control/Display Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\Tier 3 NEF (EDC7UC31)	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\Eng Engine Controller				✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580N <= NFC719059, 580SN <= NFC722013, 580SNWT <= NFC723500, 590SN <= NFC725011) (Tier 3)\VCM Vehicle Control/Display Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\Tier 4 F5C (EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580ST, 590ST, 695ST) (Tier 4A)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (Models 580SR+, 590SR, 695SR, 580ST, 590ST, 695ST)\Tier 3 NEF (EDC7UC31)	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (580SM, 580SM+, 590SM, 590SM+)\Tier 3 NEF (EDC7UC31)	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (580SM, 580SM+, 590SM, 590SM+)\VCM Vehicle Control/Display Mod	✓	✓	✓	✓		

CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (580SM, 580SM+, 590SM, 590SM+)\Eng Engine Controller				✓		
CASE\Case CE EUR (Light)\LOADER BACKHOES\Loader Backhoe (580SM, 580SM+, 590SM, 590SM+)\Trans Transmission Controller	✓			✓		
CASE\Case CE EUR (Light)\COMPACT WHEEL LOADERS\Wheel Loaders (Models 021F, 121F, 221F STD, 221F HS, 321F STD, 321F HS)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0002, S0014, S0003, S0004, S0005, S0006, S0007, S0008, S0011
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with DPF / PM-CAT)\IC Instrument Cluster	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0009, S0004, S0006, S0008, S0010, S0011
CASE\Case CE EUR (Light)\SKID STEER LOADERS\TR / TV Series Compact Track Loader and SR / SV Series Skid Steer Loader (with Tier 4 FPT Engine with SCR)\IC Instrument Cluster	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\ECM Engine Control Module				✓	A0007, A0008	S0002, S0003, S0004, S0005, S0006, S0007, S0008
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4B)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\ECM Engine Control Module				✓	A0007, A0008	S0012, S0013, S0014, S0003, S0004, S0005, S0006, S0008
CASE\Case CE EUR (Light)\FORKLIFTS\Fork Lift (Models 586H, 588H) (Tier 4A)\VCM Vehicle Control/Display/Mod	✓	✓	✓	✓		
CASE\Case CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ATC Instrument Cluster Unit	✓	✓	✓	✓		
CASE\Case CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ECM Engine Control Module				✓		
CASE\Case CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\ENG Electronic Engine Control				✓		
CASE\Case CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\JSC Joystick Steering Controller	✓			✓		
CASE\Case CE NA (Heavy)\WHEEL LOADERS\Wheel Loaders (Models 521F, 621F, 721F, 821F, 921F, 1021F, 1021F HD, 1121F) (Tier 4B)\TECM Transmission Controller						
Engine Type\Tier 3 NEF(EDC7UC31)	✓	✓	✓	✓		
Engine Type\Tier 4 F5C(EDC17C49)	✓	✓	✓	✓	A0001, A0002, A0003, A0004, A0005, A0006	S0001
Engine Type\MS6.2	✓	✓	✓	✓	Please refer to NEWHOLLAND Function List	

### Special Function Table

S0001	Engine injector code configuration(original screen with no vehicle controller backup)
S0002	Engine Restart Counter Reset/Unlock Inducement
S0003	Replacement of the Engine Oil/Filter-Reset Change Reminder
S0004	Replacement of the Exhaust Gas Recirculation Valve(EGR) – Reset ECU Data
S0005	Replacement of the Lambda Sensor-Reset ECU Data
S0006	Replacement of the Oxidant Catalyyst(OxiCat) – Reset ECU Data
S0007	Replacement of the Particulate Filter(DPF/PM-Cat) – Reset ECU Data
S0008	Replacement of the Rail Pressure Relief Valve(PRV) – Reset ECU Data
S0009	Replacement of the EGR Cooler – Reset ECU Data
S0010	Replacement of the Rail Pressure Sensor – Reset ECU Data
S0011	Replacement of the SCR Catalyst – Reset ECU Data
S0012	DPF Ash Cleaning Service – Reset ECU Data
S0013	Replacement of the Particulate Filter(DPF) – Reset ECU Data
S0014	Replacement of the Differential Pressure Sensor(Delta P)-Reset ECU Data

### Active Test Table

A0001	Compressor Air-Conditioner Relay
A0002	Injector Cut Out
A0003	Heated fuel filter relay
A0004	EOBD W/Light
A0005	Fuel Pump Relay
A0006	Cooling Fan Relay
A0007	Glow Plugs Activation Test
A0008	DPF Service Regeneration Test
A0009	Desulfurization/Thermal Conditioning Procedure
A0010	Engine – Urea Dosing System Test (UDST)