

VOITH V12.2 Function List								
Note:								
√	Functions marked with √ is fully supported.							
System			ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
DIWA. 5			√	√	√	√	A0001, A0002, A0003, A0004, A0005, A0006	
DIWA. 6			√	√	√	√	A0003, A0002, A0001, A0006, A0007, A0008, A0005, A0009, A0004	
Other			√	√	√	√	A0010, A0011, A0012	S0001

Special Function Table	
S0001	Oil change support

Active Test Table	
A0001	Clutch engage (ek)
A0002	Clutch blockage (dk)
A0003	Overdrive clutch (sk)
A0004	Quick reverse gear (rbk)
A0005	Turbine brake (tb)
A0006	Brake impulsor (pb)
A0007	Retarder valve (wp)
A0008	Retarder pressure stabilizer (wr)
A0009	Slow reverse gear (rbg)
A0010	Clock solenoid valve with~2HZ
A0011	Control solenoid vale
A0012	Reset and deleting functions